

SHR & VHR Series Heat Recovery Ventilator

IMPORTANT - PLEASE READ THIS MANUAL BEFORE INSTALLING UNIT

CAUTION - Before installation, careful consideration must be given to how this system will operate if connected to any other piece of mechanical equipment, i.e. a forced air furnace or air handler, operating at a higher static pressure. After installation, the compatibility of the two pieces of equipment must be confirmed by measuring the airflow of the Heat Recovery Ventilator using the balancing procedure found in this manual.

It is always important to assess how the operation of any HRV may interact with vented combustion equipment (i.e. Gas Furnaces, Oil Furnaces, Wood Stoves, etc.).

NEVER - install a ventilator in a situation where its normal operation, lack of operation or partial failure may result in the backdrafting or improper functioning of vented combustion equipment!!!











Your ventilation system should be installed in conformance with the appropriate provincial or state requirements or, in the absence of such requirements, with the current edition of the National Building Code, and / or ASHRAE's "Good Engineering Practices".

SHR & VHR Models

SHR 1504 • SHR 1505 R • SHR 2004 • SHR 2005 R • SHR 3005 R • SHR 3205RD VHR 1404 • VHR 1405 R • VHR 2004 • VHR 2005 R

Installation Manual

HRV MAINTENANCE CHART

Maintenance Required	Recommended Frequency	Date Maintenance Performed
Check and Clean Filters	Every 3 months or if dirty	
Check Heat Recovery Core	Every 6 months	
Check Drain Pan and Lines	Every 3 months	
Vacuum the Inside of the Unit	Annually	
Clean and Un-block Outside Hoods	Annually	
Clean and Inspect Duct Work	Annually	
General Servicing by a Qualified Contractor	Annually	

* Schedule may be altered to meet your own needs. More frequent servicing may be required depending on the severity of your home's indoor and outdoor environments.

Contractor	Telephone Number	Date Serviced

Limited Warranty

- The heat recovery aluminum core has a <u>lifetime limited warranty</u>.
- The warranty is <u>limited to 5 years on</u> <u>parts</u> and <u>Z years on fans</u> from the date of purchase, including parts replaced during this time period. If there is no proof of purchase available, the date associated with the serial number will be used for the beginning of the warranty period.
- The fans found in all Fantech HRVs require no lubrication, and are factory balanced to prevent vibration and promote silent operation.
- The limited warranty covers normal use. It does not apply to any defects, malfunctions or failures as a result of improper installation, abuse, mishandling, misapplication, fortuitous occurrence or any other circumstances outside Fantech's control.
- Inappropriate installation or maintenance may result in the cancellation of the warranty.
- Any unauthorized work will result in the cancellation of the warranty.
- Fantech is not responsible for any incidental or consequential damages incurred in the use of the ventilation system.
- Fantech is not responsible for providing an authorized service centre near the purchaser or in the general area.
- Fantech reserves the right to supply refurbished parts as replacements.
- Transportation, removal and installation fees are the responsibility of the purchaser.
- The purchaser is responsible to adhering to all codes in effect in his area.
- * This warranty is the exclusive and only warranty in effect relative to the ventilation system and all other warranties either expressed or implied are invalid.



United States

10048 Industrial Blvd. Lenexa, KS 66215 Phone: 800-747-1762; 913-752-6000 Fax: 800-487-9915; 913-752-6466 www.fantech.net; info@fantech.net

Canada

50 Kanalflakt Way, Bouctouche, NB E4S 3M5 Phone: 800.565.3548; 506.743.9500 Fax: 877.747.8116; 506.743.9600 www.fantech.net; info@fantech.net Fantech, reserves the right to modify, at any time and without notice, any or all of its products' features, designs, components and specifications to maintain their technological leadership position.